


# DSLR TERMINOLOGY



Even though each camera make and model is different, this guide will help you to easily identify basic parts and functions.

## PICTURE REVIEW BUTTON



## DIOPTR

It allows you to customize the viewfinder so that you can see a clear focused image.

## LENS ALIGNMENT MARK

Line up the matching dots to fit the lens into the mount, and then twist until it locks.

## VIEWFINDER

The main source for viewing the scene and menu options

## LCD WINDOW

## SHUTTER RELEASE

When pressed, the shutter of the camera is "released", so that it opens to take a picture.

## DEPTH OF FIELD PREVIEW

It helps you see potential depth of field

## HOTSHOE

The mounting point on the top of the camera to attach a flash unit.

## SHOOTING MODE DIAL

Sets the camera to your desired shooting mode.



## LCD CONTROL PANEL

Provides information on camera settings (ISO, white balance, battery power, number of pictures left, etc.)



## BATTERY SLOT

## TRIPOD THREAD SLOT